

# Sniper 19" TV Quick Start

## Setup for Freeview (using an aerial)

1. Connect to the cable from the antenna to the socket marked **DVB-T** on the back of the TV.
2. Switch the TV on and press the MENU button on the remote control. Select the Channel option on the left and check that TV Connection on the right shows **Air**.




If it does not show Air use the right arrow button to move to the right then select the TV Connection entry, change to Air and press OK.


3. Select Auto Search from the channel menu:



4. The select DTV, confirm that you want to do a channel search by selecting OK.



5. Wait until the search process finishes and the TV returns to the viewing mode.



# Sniper 19" TV Quick Start

## Setup for Satellite (using a dish)

1. Connect to the cable from the dish to the socket marked **DVB-S2** on the back of the TV.

2. Switch the TV on and press the MENU button on the remote control. Select the Channel option on the left and check that TV Connection on the right shows **Satellite**.



If it does not show Satellite use the right arrow button to move to the right then select the TV Connection entry, change to Satellite and press OK.

3. Select Channel Management to view the list of channels, if no channels are listed then press exit and return the menu again and select Setup and then Load Default Database.



4. Confirm that you want to do this by selecting OK and wait for the import process to finish. You should now have a channel list showing in channel management.

